

PiBox - Feature #543

Add hw type to /etc/pibox_version

28 Aug 2016 17:20 - Hammel

Status:	Closed	Start date:	28 Aug 2016
Priority:	Immediate	Due date:	
Assignee:	Hammel	% Done:	100%
Category:	00 - Basic Build Issues	Estimated time:	0.00 hour
Target version:	0.11.0		
Severity:	01 - Critical		
Description			
<p>It's not easy to figure out if a tree build is for rpi or rpi2. There are two things to do here.</p> <ol style="list-style-type: none">1. Add HW=\$(HW) to /etc/pibox_version in the scripts/postbuild.sh script.2. Add a make target to check what CT_ARCH_CPU is set to for xcc. The match is in src/xcc/xcc.\$(HW).\$(xcc-version) and the check should be in build_dir/crosstools-ng.\$(version).bld/.config. <p>The something like make show-build</p> <p>Would provide information about what the current build is for.</p>			

Associated revisions

Revision 1fce0c1 - 02 Sep 2016 21:40 - Hammel

RM #543: Add HW to pibox-version file.

History

#1 - 02 Sep 2016 21:42 - Hammel

- Status changed from New to Closed

- % Done changed from 0 to 100

Done in mjhammel/rpi2 branch. Will merge with master later.

Closing issue.